

## TETHERED TOOLS ARE MANDATORY BEYOND THIS POINT



- a) Ensure that any tools you intend to use has a certified Tool@rrest tether (applied by an authorized Retr@fit agent.
  - i) Prior to working with the tool, check the tether for any exposure to the core, ensure that the coating of the tether has not been exposed to chemical erosion and the tether tag and serial number and clearly affixed to the tether itself.
- b) Attach the tool to your lanyard, prior to using the lanyard ensure that:
  - i) The weight of the tool does not exceed the rating of the lanyard.
  - ii) There is no signs of “wear and tear”
  - iii) The lanyard must have no knots or be tangled in anyway.
  - iv) Once a lanyard has experience a drop, remove from service immediately and report the incident to your H&S Manager.
- c) Please ensure that the weight of the tool does not exceed 2kg where you attach to the wrist, or 2.5kg where you attach the body. In the instance that it’s unavoidable that you use a tool exceeding these weights, ensure that you attach the lanyard to a rated fixed point **only**.

